

Instructions to adhere foam bulkheads in Prijon kayaks

- 1. Place the clean bulkhead as usual in the appropriate place in the boat or, if the bulkhead is already glued, completely remove the adhesive in the damaged area.
- 2. Apply a thin and even layer of primer to both bonding edges (inside and outside of the bulkhead) using a clean cloth or brush (both on the hull and on the foam) and allow to dry for about 15 minutes.
- **3.** Use 2-component adhesive to glue the bulkhead to the hull on both sides and allow the adhesive to dry for 30 minutes.
- **4.** Finally, seal the now dried bond on both sides with silicone compound.

Then let the adhesive dry for a full day. Please do not move or transport the boat during this time.

You will receive:

1 PE bottle with primer

1 small 2-component adhesive mixing cartridge 1 black slider for the mixing cartridge 1 mixing nozzle for the mixing cartridge

1 large cartridge of silicone compound

To complete the work, you will need:

A clean cloth or brush for applying the primer.

A cartridge gun for applying the silicone sealant.