

## PURE Outfitting

### Adjustment of the new 3-D-Thigh braces in the PURE.


#### **Move position of thigh brace forward and backward:**

Open the middle screw and take it out completely.

Put the nut with the rounded side to top into one of the 4 gaps as shown on the picture.

Now put the brace together with the nut into position and tighten the middle screw.

**Attention:** Take care that the round side of the nut is on top!



#### **Move brace from flat to aggressive position:**

Open middle screw one full turn, pull the brace into the position you prefer and tighten the screw again.



#### **Adjustment of the leg angle:**


Open all screws one full turn. Move the brace with the adaptor part in or out in front and tighten all screws again.



### **Adjustable footplate PURE**

Depending on the position of the plate in the boat the footplate can be adjusted in height. This avoids a big open gap on top of the plate for kayakers with short legs.

Open the two screws between the foam pads about 1 full turn. Then slip the foot plate up or down and fix the position tightening the screws.



### **Shock Absorber Footplate:**

The footplate can be adjusted with the belts to fit the paddler when sitting in the boat.



### **Seat adjustments PURE:**

Width of the seat can be adjusted with foam parts.

With foam: seat is narrow.



Without foam: seat is wider.



Center foam can be moved forward and backwards to adjust the seat position.



### **The complete seat can be moved forward and backwards.**

Open the screws left and right about 2 full turns. Then move the seat into position and tighten the screws.

